



NOTES

DOWEL AND TUBE FIT NOT CRITICAL-DOWEL NEEDS TO BE A SLIP FIT INSIDE THE ALUMINUM TUBE TO ALLOW LATERAL MOVEMENT. IMPORTANT-DO NOT LEAVE SHARP EDGES ON THE END OF THE SLIDING PIN TO AVOID BINDING WITH THE STAB KEYS DURING THE STAB POP-UP ACTION. SET STAB KEYS SUCH THAT THEY MAKE LIGHT CONTACT WITH THE END OF THE SLIDING PIN, FIN CENTERED RELATIVE TO THE FUSELAGE.

CB Model Designs

Ramrod 280 Adjustable Stab Key Installation

SCALE 1:1

REV N/C

SHEET 1 OF 1